

Ultra Clean Capsule Dispenser Stand UC-CDS

Loading and Feeding Instructions



Start by removing the magnetic disk from the Capsule Wand.

Then take your stick of capsules, remove the first capsule, and insert the magnetic disk inside. Then place the remaining capsules on top.



Take the correct sized dispensing tube for the capsule size you have prepared. Pull back the lid and insert the stick of capsules. Close the lid once the stick of capsules has been fully inserted into the dispensing tube.



Place the protruding tongue, located on the rear side of the dispensing tube, into your desired groove located at the top of the dispensing stand. Then place the bottom side of the dispensing tube, equipped with a magnet, onto the magnetic strip. These will secure your dispensing tube in place to prevent shifting or jostling while in use.



Take the Capsule Wand and insert it into the bottom opening of the dispensing tube. The magnetic disk that was inserted into the lead capsule will affix itself to the wand. Slowly pull the lead capsule out with the wand. Now that the capsules have been fed through the dispensing tube, all subsequent capsules will immediately dispense. Be sure to retrieve the magnetic disk from the lead capsule when finished. When the tube depletes to about a quarter stick of capsules, insert another stick of capsules to bypass the feeding process.